

SONY®

5-001-350-11(1)

Wireless Stereo Headset
Casque stéréo sans fil

Reference Guide Manuel de référence Guía de referencia



WI-C200 / WI-C310

http://rd1.sony.net/help/mdr/wf1000xm2/h_zz/



©2019 Sony Corporation
Printed in China
Imprimé en Chine

http://www.sony.net/

English

Wireless Stereo Headset

CAUTION: Risk of fire and burns. Do not open, crush, heat above 60 °C (140°F) or incinerate.

RECYCLING RECHARGEABLE BATTERIES

Rechargeable batteries are recyclable. You can help preserve our environment by returning your used rechargeable batteries to the collection and recycling location nearest you.

For more information regarding recycling of rechargeable batteries, visit <http://www.sony.com/electronics/eco/environmental-management>. Caution: Do not handle damaged or leaking rechargeable batteries.

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that is deemed to comply without testing of specific absorption rate (SAR).

FOR UNITED STATES CUSTOMERS. NOT APPLICABLE IN CANADA, INCLUDING IN THE PROVINCE OF QUEBEC.

POUR LES CONSOMMATEURS AUX ÉTATS-UNIS. NON APPLICABLE AU CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

If you have any questions about this product:

Visit: www.sony.com/support
Contact: Sony Customer Information Service Center at 1-800-222-7669

Write: Sony Customer Information Service Center 12451 Gateway Blvd., Fort Myers, FL 33913

Supplier's Declaration of Conformity

Trade Name : SONY
Model : WI-C200 / WI-C310
Responsible Party : Sony Electronics Inc.
Address : 16535 Via Esprillo, San Diego, CA 92127 U.S.A.
Telephone Number : 858-942-2230

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment must not be co-located or operated in conjunction with any other antenna or transmitter.

For the customer in Canada

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

High volume may affect your hearing.

Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

Do not use at a dangerous place unless the surrounding sound can be heard.

The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately and consult your nearest Sony dealer. In particular, be careful in the following cases:
– When using the unit around a sink, etc.
Be careful that the unit does not fall into a sink or container filled with water.
– When using the unit in the rain or snow, or in humid locations
– When using the unit while you are sweaty
If you touch the unit with wet hands or put the unit in the pocket of a damp article of clothing, the unit may get wet.

For details on the effect of contact to the human body from the mobile phone or other wireless devices connected to the unit, refer to the instruction manual of the wireless device.

Install the earbuds firmly. Otherwise, they may detach and be left in your ears, resulting in injury or illness.

There is a danger that small parts may be swallowed. After use, store in a location out of the reach of small children.

Note on static electricity

Static electricity accumulated in the body may cause mild tingling in your ears. To reduce the effect, wear clothes made from natural materials, which suppress the generation of static electricity.

IMPORTANT: THE VOICE GUIDANCE FOR THIS UNIT IS ONLY AVAILABLE IN ENGLISH.


The voice guidance can be heard from the unit when:

- When powering on: "Power on"
- When powering off: "Power off"
- When the remaining battery level is low and recharge is recommended: "Low battery, please recharge headset"
- When automatically turning off due to low battery: "Please recharge headset. Power off"
- When entering pairing mode: "Bluetooth pairing"
- When establishing a Bluetooth connection: "Bluetooth connected"
- When disconnecting a Bluetooth connection: "Bluetooth disconnected"

Precautions

On BLUETOOTH® communications

- Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
- Bluetooth communications may not be possible, or noise or audio dropout may occur under the following conditions:
 - When there is a person between the unit and the Bluetooth device. This situation may be improved by positioning the Bluetooth device so that it faces the antenna of the unit.
 - When there is an obstacle, such as a metal object or a wall, between the unit and the Bluetooth device.
 - When a Wi-Fi device or microwave oven is in use, or microwaves are emitted near the unit.
 - Compared to use indoors, use outdoors is subjected little to signal reflection from walls, floors, and ceilings, which results in audio dropout occurring more frequently than use indoors.
- The antenna is built into the unit as indicated by the dotted line in the illustration below. The sensitivity of the Bluetooth communications can be improved by removing any obstacles between the connected Bluetooth device and the antenna of this unit.



- Bluetooth and Wi-Fi (IEEE802.11b/g/n) devices use the same frequency (2.4 GHz). When using the unit near a Wi-Fi device, electromagnetic interference may occur, resulting in noise, audio dropout, or the inability to connect. If this happens, try performing the following remedies:
 - Establish a connection between the unit and the Bluetooth device when they are at least 10 m (30 feet) away from the Wi-Fi device.
 - Turn off the Wi-Fi device when using the unit within 10 m (30 feet) of the Wi-Fi device.
 - Position the unit and the Bluetooth device as near as possible to each other.
- Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices. Turn off this unit and other Bluetooth devices in the following locations, as it may cause an accident:
 - in hospitals, near priority seating in trains, locations where inflammable gas is present, near automatic doors, or near fire alarms.
- The audio playback on this unit may be delayed from that on the transmitting device, due to the characteristics of Bluetooth wireless technology. As a result, the sound may not be in sync with the image when viewing movies or playing games.
- This product emits radio waves when used in wireless mode. When used in wireless mode on an airplane, follow flight crew directions regarding permissible use of products in wireless mode.
- The unit supports security functions that comply with the Bluetooth standard as a means of ensuring security during communication using Bluetooth wireless technology. However, depending on the configured settings and other factors, this security may not be sufficient. Be careful when communicating using Bluetooth wireless technology.
- Sony shall assume no responsibility for any damages or loss resulting from information leaks that occur when using Bluetooth communications.
- Connection with all Bluetooth devices cannot be guaranteed.
 - Bluetooth devices connected with the unit must comply with the Bluetooth standard prescribed by Bluetooth SIG, Inc., and must be certified as compliant.
 - Even when a connected device complies with the Bluetooth standard, there may be cases where the characteristics or specifications of the Bluetooth device make it unable to connect, or result in different control methods, display, or operation.
 - When using the unit to perform hands-free talking on the phone, noise may occur depending on the connected device or the communication environment.
- Depending on the device to be connected, it may require some time to start communications.

If sound skips frequently during playback


- The situation may be improved by changing the wireless playback quality settings or fixing the wireless playback mode to SBC on the transmitting device. For details, refer to the operating instructions supplied with the transmitting device.
- When listening to music from a smartphone, the situation may be improved by closing unnecessary apps or restarting the smartphone.

On the use of calling apps for smartphones and computers

- This unit supports normal incoming calls only. Calling apps for smartphones and computers are not supported.


On charging the unit

- This unit can be charged using USB only. A computer with a USB port or a USB AC adaptor is required for charging.
- Be sure to use the supplied USB Type-C cable.
- When charging, the unit cannot be turned on and the Bluetooth function cannot be used.
- If the unit is not used for a long time, the rechargeable battery may become depleted quickly. The battery will be able to hold a proper charge after it is discharged and recharged several times. When storing the unit for a long time, charge the battery once every six months to prevent over-discharge.
- If the rechargeable battery becomes depleted extremely quickly, it should be replaced with a new one. Please contact your nearest Sony dealer for a battery replacement.
- Make sure to close the USB Type-C port cover securely after charging. Perspiration or water may cause damage.



If the unit does not operate properly

- Follow the procedure below to reset the unit.
Press the and buttons simultaneously while the unit is charging. The unit is reset. When the unit is reset, the pairing information in the unit is not deleted.



- If the problem persists even after the unit is reset, perform the procedure below to initialize the unit.
Disconnect the USB Type-C cable and turn off the unit. Press and hold the and buttons simultaneously for at least 7 seconds. The indicator (blue) flashes 4 times, the unit is initialized, and the unit is reset to the factory settings. When the unit is initialized, all pairing information is deleted.
- After the unit is initialized, it may not connect to your iPhone or computer. If this happens, delete the pairing information of the unit from the iPhone or computer, and then pair them again.

Notes on wearing the unit


- After use, remove the headphones slowly.
- Because the earbuds achieve a tight seal in the ears, forcibly pressing them in or quickly pulling them out can result in eardrum damage. When putting the earbuds into your ears, the speaker diaphragm may produce a click sound. This is not a malfunction.
- **Other notes**
 - Do not subject the unit to excessive shock.
 - The Bluetooth function may not work with a mobile phone, depending on the signal conditions and the surrounding environment.
 - If you experience discomfort while using the unit, stop using it immediately.
 - The earbuds may be damaged or deteriorate with long-term use and storage.
 - If the earbuds become dirty, remove them from the unit and gently wash them by hand using a neutral detergent. After cleaning, thoroughly wipe off any moisture.

Cleaning the unit

- When the outside of the unit is dirty, clean it by wiping with a soft dry cloth. If the unit is particularly dirty, soak a cloth in a dilute solution of neutral detergent, and wring it well before wiping. Do not use solvents such as thinner, benzene, or alcohol, as they may damage the surface.
- If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

Replacement parts: hybrid silicone rubber earbuds
Please consult your nearest authorized Sony retailer or www.sony.com for information about replacement parts.

Location of the serial number label



Specifications

Headset

Power source:
DC ##xx## V: Built-in lithium-ion rechargeable battery
DC 5 V: When charged using USB

Operating temperature:
0 °C to 40 °C (32 °F to 104 °F)

Rated power consumption:
##xx## W

Usage hours:
When connecting via the Bluetooth device
Music playback time: Max. ##xx## hours
Communication time: Max. ##xx## hours
Standby time: Max. ##xx## hours
Note: Usage hours may be shorter depending on the Codec and the conditions of use.

Charging time:
Approx. ##xx## hours
(About ##xx## minutes of music playback is possible after 10 minutes charging.)
Note: Charging and usage hours may be different depending on the conditions of use.

Charging temperature:
5 °C to 35 °C (41 °F to 95 °F)

Mass:
Approx. ##xx## g (##yy## oz)
(main unit approx. ##xx## g (##yy## oz))

Included items:
Wireless Stereo Headset (1)
USB Type-C™ cable (USB-A to USB-C™) (approx. ##xx## cm (##yy## in.)) (1)
Hybrid silicone rubber earbuds (S (2 lines) (2), M (3 lines) (attached to the unit at the factory) (2), L (4 lines) (2)) or (S (orange) (2), M (green) (attached to the unit at the factory) (2), L (light blue) (2))

Communication specification

Communication system:
Bluetooth Specification version ##xx##

Output:
Bluetooth Specification Power Class ##xx##

Maximum communication range:
Line of sight approx. ##xx## m (##yy## ft)†

Frequency band:
2.4 GHz band (2.4000 GHz - 2.4835 GHz)

Compatible Bluetooth profiles†:
A2DP / AVRCP / HFP / HSP

Supported Codec†:
SBC / AAC

Transmission range (A2DP):
20 Hz - 20,000 Hz (Sampling frequency 44.1 kHz)

† The actual range will vary depending on factors such as obstacles between devices, magnetic fields around a microwave oven, static electricity, reception sensitivity, antenna's performance, operating system, software application, etc.

‡ The actual range will vary depending on factors such as obstacles between devices, magnetic fields around a microwave oven, static electricity, reception sensitivity, antenna's performance, operating system, software application, etc.

§ Bluetooth standard profiles indicate the purpose of Bluetooth communications between devices.

Design and specifications are subject to change without notice.

System requirements for battery charge using USB

USB AC adaptor

A commercially available USB AC adaptor capable of supplying an output current of ##xx## or more

Trademarks

- iPhone and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
- Android is a trademark of Google LLC.
- The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license.
- USB Type-C™ and USB-C™ are trademarks of USB Implementers Forum.
- Other trademarks and trade names are those of their respective owners.

Français

Casque stéréo sans fil

ATTENTION : Risque d'incendie et de brûlures. Ne l'ouvrez pas, ne l'émettez pas, ne le faites pas chauffer à plus de 60 °C (140°F) ou ne l'incinérerez pas.

RECYCLAGE DES ACCUMULATEURS RECHARGEABLES

Les accumulateurs rechargeables sont recyclables. Vous pouvez contribuer à préserver l'environnement en rapportant les piles usées dans un point de collection et recyclage le plus proche. Pour plus d'informations sur le recyclage des accumulateurs, visitez <http://www.sony.com/electronics/eco/environmental-management>. Avertissement: Ne pas utiliser des accumulateurs rechargeables qui sont endommagés ou qui fuient.

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles les radioélectriques (RF) de la FCC lignes directrices d'exposition et d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'ISDE. Cet équipement émet une énergie RF très faible qui est considérée comme conforme sans évaluation du débit d'absorption spécifique (DAS).

Pour la clientèle au Canada

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux deux conditions suivantes :
1) l'appareil ne doit pas produire de brouillage;
2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement

Un volume élevé peut affecter votre ouïe.

N'utilisez pas l'appareil pendant que vous marchez, conduisez ou faites du vélo. Vous risqueriez de provoquer des accidents de la circulation.

Ne l'utilisez pas à un endroit dangereux, à moins que vous puissiez entendre les sons environnants.

L'appareil n'est pas résistant à l'eau. Si de l'eau ou des corps étrangers pénètrent dans l'appareil, cela peut entraîner un incendie ou un choc électrique. Si de l'eau ou un corps étranger pénètre dans l'appareil, cessez immédiatement de l'utiliser et consultez votre détaillant Sony le plus proche. N'oubliez pas de suivre, notamment, les précautions ci-dessous.

- Utilisation près d'un évier, etc.
- Veillez à ce que l'appareil ne tombe pas dans un évier ou un récipient rempli d'eau.
- Utilisation sous la pluie ou la neige ou dans des endroits humides
- Utilisation pendant que vous transpirez
- Si vous touchez l'appareil avec les mains mouillées ou le mettez dans la poche d'un vêtement humide, l'appareil peut devenir mouillé.

Pour plus de renseignements sur l'effet de contact sur le corps humain que peut avoir un téléphone mobile ou autre périphérique sans fil connecté à l'appareil, consultez le manuel d'instructions du périphérique sans fil.

Installez fermement les oreillettes. Sinon, elles peuvent se détacher et rester dans vos oreilles, entraînant des blessures ou des maladies.

Il y a un risque que les petites pièces puissent être avalées. Après l'utilisation, rangez-le dans un endroit hors de portée des enfants.

Remarque sur l'électricité statique

L'électricité statique accumulée dans votre corps peut causer une légère sensation de picotement dans vos oreilles. Pour réduire l'effet, portez des vêtements fabriqués à partir de matériaux naturels, qui permettent d'éviter la production d'électricité statique.

IMPORTANT : LE GUIDAGE VOCAL POUR CET APPAREIL EST UNIQUEMENT DISPONIBLE EN ANGLAIS.


Le guidage vocal peut se faire entendre en provenance de l'appareil :
• Lors de la mise en marche : « Power on » (Marche)
• Lors de la mise en arrêt : « Power off » (Arrêt)

- Lorsque le niveau restant de la batterie est faible et qu'une recharge est recommandée : « Low battery, please recharge headset » (Batterie faible, veuillez recharger le casque d'écoute)
- Lors de la mise en arrêt automatique en raison de la batterie faible : « Please recharge headset. Power off » (Veuillez recharger le casque d'écoute. Arrêt)
- Lorsque l'appareil passe en mode de jumelage : « Bluetooth pairing » (Jumelage Bluetooth)
- Lors de l'établissement d'une connexion Bluetooth : « Bluetooth connected » (Bluetooth connecté)
- Lors de la désactivation d'une connexion Bluetooth : « Bluetooth disconnected » (Bluetooth déconnecté)

Précautions

À propos des communications BLUETOOTH®

- La technologie sans fil Bluetooth fonctionne dans un rayon d'environ 10 m (30 pieds). La distance maximale de communication peut varier en fonction de la présence d'obstacles (personnes, objets métalliques, murs, etc.) ou de l'environnement électromagnétique.
- Les communications Bluetooth peuvent ne pas être possibles ou du bruit ou des pertes sonores peuvent se produire dans les conditions suivantes :
 - Lorsqu'il y a une personne entre l'appareil et le périphérique Bluetooth. Cette situation peut être améliorée en plaçant le périphérique Bluetooth de manière à ce qu'il soit face à l'antenne de l'appareil.
 - Lorsqu'il y a un obstacle, tel qu'un objet métallique ou un mur, entre l'appareil et le périphérique Bluetooth.
 - Lorsqu'un périphérique Wi-Fi ou un four à micro-ondes est en cours d'utilisation ou que des micro-ondes sont émises à proximité de l'appareil.
 - Comparativement à une utilisation intérieure, l'utilisation extérieure est peu soumise à la réflexion du signal sur les murs, les sols et les plafonds, ce qui entraîne une perte sonore plus fréquente que lors de l'utilisation à l'intérieur.
 - L'antenne est intégrée à l'appareil comme l'indique la ligne en pointillé sur l'illustration ci-dessous. La sensibilité des communications Bluetooth peut être améliorée en retirant tout obstacle entre le périphérique Bluetooth connecté et l'antenne de cet appareil.



- Les périphériques Bluetooth et Wi-Fi (IEEE802.11b/g/n) utilisent la même fréquence (2,4 GHz). Lors de l'utilisation de l'appareil à proximité d'un périphérique Wi-Fi, des interférences électromagnétiques peuvent se produire, entraînant du bruit, des pertes sonores ou l'impossibilité de se connecter. Si cela se produit, essayez les solutions suivantes :
 - Établissez une connexion entre l'appareil et le périphérique Bluetooth lorsqu'ils sont à moins de 10 m (30 pieds) du périphérique Wi-Fi.

- Désactivez le périphérique Wi-Fi lorsque vous utilisez l'appareil à moins de 10 m (30 pieds) du périphérique Wi-Fi.
- Placez l'appareil et le périphérique Bluetooth aussi près que possible l'un de l'autre.

- Les micro-ondes émises par un périphérique Bluetooth peuvent nuire au fonctionnement des dispositifs médicaux électroniques. Désactivez cet appareil et tout autre périphérique Bluetooth dans les endroits suivants, car cela peut entraîner un accident :
 - dans les hôpitaux, à proximité des places prioritaires dans les trains, aux endroits où des gaz inflammables sont présents, près des portes automatiques ou près des alarmes d'incendie.

- La lecture audio sur cet appareil peut être retardée par rapport à celle sur le périphérique émetteur en raison des caractéristiques de la technologie sans fil Bluetooth. Par conséquent, le son pourrait ne pas être synchronisé avec l'image lorsque vous visionnez un film ou jouez à un jeu.
- Ce produit émet des ondes radio lors de l'utilisation en mode sans fil. Lors de l'utilisation en mode sans fil dans un avion, suivez les instructions de l'équipage concernant l'utilisation permise des produits en mode sans fil.

- L'appareil prend en charge les fonctions de sécurité conformes à la norme Bluetooth en tant que moyen d'assurer la sécurité lors de la communication à l'aide de la technologie sans fil Bluetooth. Cependant, en fonction de la configuration des paramètres et d'autres facteurs, cette sécurité peut ne pas être suffisante. Faites attention lors de vos communications à l'aide de la technologie sans fil Bluetooth.

- Sony n'assume aucune responsabilité pour tout dommage ou perte résultant de fuites d'informations se produisant lors de l'utilisation des communications Bluetooth.

- La connexion avec tous les périphériques Bluetooth ne peut pas être garantie.

- Les périphériques Bluetooth connectés à l'appareil doivent être conformes à la norme Bluetooth prescrite par Bluetooth SIG, Inc., et doivent être certifiés comme étant conformes.
- Même lorsqu'un périphérique connecté est conforme à la norme Bluetooth, il peut y avoir des cas où les caractéristiques ou les spécifications du périphérique Bluetooth rendent la connexion impossible ou entraînent des différences dans les méthodes de commande, l'affichage ou le fonctionnement.
- Lors de l'utilisation de l'appareil pour des appels en mode mains libres, du bruit peut se produire en fonction du périphérique connecté ou de l'environnement de communication.

- En fonction du périphérique à connecter, un certain temps peut être nécessaire pour amorcer les communications.

Si le son saute fréquemment pendant la lecture


- La situation peut être améliorée en modifiant les paramètres de qualité de lecture sans fil ou en réglant le mode de lecture sans fil à SBC sans le périphérique émetteur. Pour plus de détails, consultez le mode d'emploi fourni avec le périphérique émetteur.
- Lorsque vous écoutez de la musique à partir d'un téléphone intelligent, la situation peut être améliorée en fermant les applications inutiles ou en redémarrant le téléphone intelligent.

À propos de l'utilisation des applications d'appel pour les téléphones intelligents et les ordinateurs

- Cet appareil prend seulement en charge les appels entrants normaux. Les applications d'appel pour les téléphones intelligents et les ordinateurs ne sont pas prises en charge.

À propos de la charge de l'appareil

- Cet appareil peut seulement être chargé par USB. Un ordinateur avec un port USB ou un adaptateur CA USB est requis pour la charge.
- Assurez-vous d'utiliser le câble USB Type-C fourni.
- Lors de la charge, l'appareil ne peut pas être mis en marche et la fonction Bluetooth ne peut pas être utilisée.
- Si l'appareil n'est pas utilisé pendant une longue période, la batterie rechargeable peut se vider rapidement. La batterie pourra fournir une charge appropriée après avoir été déchargée et rechargée plusieurs fois. Lorsque vous rangez l'appareil pendant une longue période, chargez la batterie une fois tous les six mois afin de prévenir la décharge excessive.
- Si la batterie rechargeable se vide très rapidement, elle doit être remplacée par une nouvelle. Veuillez communiquer avec votre détaillant Sony le plus proche pour obtenir une batterie de rechange.
- Assurez-vous de fermer le couvercle du port USB Type-C fermement après la charge. La transpiration ou l'eau peut causer des dommages.



Si l'appareil ne fonctionne pas correctement

- Suivez la procédure ci-dessous pour réinitialiser l'appareil. Appuyez simultanément sur les boutons et pendant que l'appareil est en charge. L'appareil est réinitialisé. Après la réinitialisation de l'appareil, les informations de jumelage dans l'appareil sont toujours présentes.

