OT PRINT PINK DIELINE
SIZE: A5 (148mm x 210mm)

CTROLA™

etooth® Tower Stereo

Model: VS-160

Instruction Manual

REFULLY BEFORE OPERATING THIS EQUIPMENT.
H A SAFE PLACE FOR FUTURE REFERENCE.

IMPORTANT SAFETY INSTRUCTIONS

CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

DANGEROUS VOLTAGE: The lighting flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

ATTENTION: The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

WARNING: USE UNDER THE SUPERVISION OF AN ADULT DUE TO THE LONG CORD
This unit has a long cord that can be easily tripped on or pulled on, causing injury. Please make sure it is arranged so that it will not drape over a tabletop, etc. Where it can be pulled on by children or tripped over accidentally.

FCC NOTICE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC STATEMENT:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation. The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC WARNING:
To assure continued operation, follow the attached installation instructions and use only shield cables when connecting to other devices. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SAFETY INSTRUCTIONS:
Before using the unit, be sure to read all operating instruction carefully, please note that these are general precautions and may not pertain to your unit. For example, this unit may not have the capability to be connected to an outdoor antenna.

1. **Read these instructions**
   All the safety and operating instructions should be read before the appliance is operated.
2. **Keep these instructions**
   The safety and operating instructions should be kept for future reference.
3. **Heed all warnings**
   All warnings on the appliance and in the operating instructions should be adhered to.
4. **Follow all instructions**
   All operation and use instructions should be followed.
5. **Do not use this apparatus near water**
   The appliance should not be used near water; for example, near a bath tub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.
6. **Clean only with dry cloth**
   The appliance should be cleaned only as recommended by the manufacturer.
7. **Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.** Slots and openings in the cabinet and in the back or bottom are provided for ventilation, to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or similar surface. This product should never be placed near or over a radiator or heat source. This product should not be placed in a built-in installation, such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
8. **Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.**
9. **Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.**
10. **Prevent the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.**
11. **Only use attachments / accessories specified by the manufacturer.**
12. **Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart / apparatus combination to avoid injury from tip-over.** An appliance and cart combination should be moved with care. Quick stop, excessive force and uneven surfaces may cause the appliance and cart combination to overturn.
13. **Unplug this apparatus during lightning storms or when unused for long periods of time.** To protect your product from a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
14. **Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.**
15. **Power source**
    This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For products intended to operate from battery power, or other source, refer to the operation instructions.
16. **Power lines**
    An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
17. **Overloading**
    Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.
18. **Object and liquid entry**
    Never push objects of any kind into the product through openings as they may touch dangerous voltage points or short out parts that could result in fire or electric shock. Never spill or spray any type of liquid on the product.
19. **Outdoor antenna grounding**
    If an outside antenna is connected to the product, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges. Section 810 of the National Electric Code ANSI/NFPA 70 provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge product, size of grounding conductors, location of antenna-discharge product, connection to grounding electrodes and requirements for the grounding electrodes.



20. **Replacement parts**
    When replacement parts are required, be sure the service technician u
    replacement parts specified by the manufacturer or those that have th
    characteristics as the original parts. Unauthorized substitutions may r
    or electric shock or other hazards.
21. **Safety check**
    Upon completion of any service or repairs to this product, ask the ser
    technician to perform safety checks to determine that the product is i
    operating condition.
22. **Wall or ceiling mounting**
    The product should be mounted to a wall or ceiling only as recommen
    manufacturer.
23. **Damage requiring service**
    Unplug this product from the wall outlet and refer service to qualified
    personnel under the following conditions:
    a) When the power supply cord or plug is damaged.
    b) If liquid has been spilled or objects have fallen into the product.
    c) If the product has been exposed to rain or water.
    d) If the product does not operate normally by following the operating
       instructions. Adjust only those controls that are covered by the ope
       instructions, as an adjustment of other controls may result in dama
       require extensive work by a qualified technician to restore the prod
       normal operation.
    e) If the product has been dropped or the cabinet has been damaged
    f) When the product exhibits a distinct change in performance- this in
       need for service.
24. **Note to CATV system installer**
    This reminder is provided to call the CATV system installer's attention
    820-40 of the NEC that provides guidelines for proper grounding and,
    particular, specifies that the cable ground shall be connected to the g
    system of the building, as close to the point of cable entry as practica

**NOTE: Refer all servicing to qualified service personnel. Servicing is r
when the unit has been damaged in any way such as the following: th
power-supply cord or plug has been damaged, liquid has been spilled
the unit has been exposed to rain or moisture, the unit has been drop
unit does not operate normally.**

CALIFORNIA PROP 65 WARNING

WARNING: This product can expose you to chemicals including
which is known to the State of California to cause cancer and bi
or other reproductive harm. For more information go to
www.P65Warnings.ca.gov.

SPECIFICATIONS

E	AC 100-240V~50/60Hz
E	DC 9V ⎓ 2A
ION	4W
ER SIZE	5.25" (133.35mm)
	3.5mm Auxiliary Cable
	Bluetooth®
E	Up to 10 meters (33 ft)
	10.5 lbs (7 kgs)
IONS	32.875" H x 7.75" W x 7.75" D
	835mm H x 196.85mm W x 196.85mm D
	AC Adaptor
	Instruction Manual
	3.5mm Auxiliary Cord

ut of continual improvements, the design and specifications of
et to change without notice.

ed trademark of Bluetooth SIG, Inc.
d trade names are those of their respective owners.

FUNCTIONS AND CONTROLS



1. **VOLUME CONTROL KNOB:** Increase/Decrease master volume
2. **TREBLE CONTROL KNOB:** Turn to adjust the level of high frequencies
3. **BASS CONTROL KNOB:** Turn to adjust the level of low frequencies
4. **AUX INPUT:** Connect external media player using 3.5mm auxiliary cable
   The Bluetooth indicator will remain solid.
5. **BLUETOOTH INDICATOR:** The indicator will flash once the unit is ON.
   The Bluetooth indicator will flash quickly while searching for a Bluetooth device. Once an external device is connected, it will flash slowly.
6. **POWER:** Turn ON/OFF the unit's power supply

GENERAL OPERATION

POWER SOURCE:
Insert the adaptor plug into a conveniently located AC outlet with 100-240V~50/60Hz.

WARNING: This unit has a long cord that can easily be tripped on or pulled on, causing injury. Please make sure it is arranged so it will not drape over a tabletop, etc. where it can be pulled on by children or tripped over accidentally.

BLUETOOTH MODE:
1. Power on the unit and it will be Bluetooth mode. The speaker will automatically enter pairing mode and make a beeping sound.
2. Activate Bluetooth function on your external Bluetooth device and select **"VS-160"** from your device's Bluetooth settings menu.
3. Once paired, the unit will make a confirmation tone indicating that the connection was successful. You can now start playback on your connected device to begin streaming music to the speaker.
4. If you want to connect a different Bluetooth device, press the "disconnect" button on your device to disconnect the speaker. Follow the steps above to pair a different device.

NOTE: The unit will automatically be connected with the last paired and connected device once both of them are in Bluetooth mode and in Bluetooth range.

NOTE: You can control your music from your external device ONLY and not through the unit's control panel when using Bluetooth Mode.

AUX-IN MODE:
1. Power on the unit and securely connect one end of the Aux-In Cable into the AUX-IN JACK, and the other end into your external device's headphone jack. To start playback, play music through your external device.

NOTE: You can control your music from your external device ONLY and not through the unit's control panel when using AUX-IN Mode.

TROUBLESHOOTING GUIDE

If you are having problems with your unit, please review the guide below.

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
No power	Power plug is not plugged into a wall outlet.	Plug into the wall outlet properly.
No sound	Volume is set to minimum.	Increase the volume level by using the Volume Knob.
	The connected device is not in playing mode.	Play the music from the connected device.
	Sound output of the connected device is set too low.	Increase the volume level of the connected device.
Sound distortion.	Volume level is too high.	Reduce the volume level by using the Volume Knob.
	Volume level of the connected device is set too high.	Reduce the volume level of the connected device.
Bluetooth not pairing	The external device is too far from the unit.	Bring the external Bluetooth device closer to the unit.
	Failed pairing and connection.	Turn unit off and on again. Then try to re-pair your device.

WARRANTY

Innovative Technology Electronics LLC.
Limited Warranty: 90 Days Labor, One Year Parts

Innovative Technology Electronics LLC. (IT) warrants the product to be fre
"Defects" in materials under normal use for a period of "One Year" from th
original purchase. The Warranty is "Not" transferable. IT agrees, within the
Day" period, to repair or replace the product if it is determined to be defec
Charge". It is further agreed that IT will cover the cost to repair or replace
"Parts" only for a total period of "One Year" from the date of the original p
warranty does not cover cosmetic damage, antennas, AC cords, cabinets,
ear-pads, or damage due to line power surges, connection to improper an
or settings, misuse, mishandling, accident, acts of God or attempted repai
unauthorized service agent.

**To obtain service, the purchaser MUST present an original sales recei
purchase. Please contact us at www.victrola.com to request an RMA
Material Authorization) number to return products for service or repla**
Returns without an RMA number on the package will be refused and return
sender. Upon receipt of the returning item and our full inspection (IT) may
replacement to customer for the same item or of one that has equivalent
features. To return an item, supply full name, return address, phone numb
purchased, receipt of purchase and reason for return to obtain RMA numb

All returns must be in the original packaging or reasonable substitute to p
damage. Customer "Must" include full name, shipping address and telep
inside of package. No return will be shipped back to a PO Box or APO ad

Please include your check or money order in the amount of:
- **USD $5.00 for items $10.00 to $39.99. (Price Paid Per Unit)**
- **USD $10.00 for items $40.00 to $99.99. (Price Paid Per Unit)**
- **USD $15.00 for items $100.00 and up. (Price Paid Per Unit)**
- **Shipping fees are non-refundable**

to be payable to Innovative Technology Electronics LLC. (for handling and
shipping charges) (IT) will not be responsible for delays or unprocessed cl
resulting from a purchaser's failure to provide any / all of the necessary inf
Send all inquiries or RMA request via our website
www.victrola.com/pages/technical-support.

Innovative Technology Electronics LLC.
1 Channel Drive
Port Washington, NY 11050
Toll free: 1-877-480-3487
Website for support: www.victrola.com/pages/technical-support

There are no express warranties except as listed above.
REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS
EXCLUSIVE REMEDY OF THE CUSTOMER. IT SHALL NOT BE LIABLE F
INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EX
IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT PR
APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY O
FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURA
THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or conse
damages, or limitations on how long an implied warranty lasts, so the abo
exclusions or limitations may not apply to you. This warranty gives you sp
rights and you may also have other rights, which vary from state to state.