


FIRE STORM

Gaming Desk



Item#: 33906167

Customer Service:
800-747-2660

ATLANTIC®

Ver. 01 11/11/20

Assembly Tips:

Become familiar with the instructions and all parts. Make sure that all parts are in the box and in good condition. Assemble the product on the open flat carton or a rug to protect the product and your floor. Some heavy products need a second person to assist in the assembly. Use of power tools is not recommended.

Care Instructions:

Use electrostatic dust cloths to clean furniture.
Do not set hot or cold containers directly on the furniture surface.

Consejos para armar:

Familiarícese con las instrucciones y todas las piezas. Asegúrese de que todas las partes estén en la caja y en buenas condiciones. Arme el producto sobre la caja de cartón plana abierta o una alfombra para proteger el producto y su piso. Algunos productos pesados necesitan una segunda persona para ayudar a armarlos. No se recomienda el uso de herramientas eléctricas.

Instrucciones para el cuidado:

Utilice paños de polvo electrostáticos para limpiar los muebles. No coloque recipientes calientes o fríos directamente sobre la superficie de los muebles.



Caution:

Never let children climb on furniture or play with furniture. Do not place a weight heavier than the recommended load rating on the furniture surface.

Use care when moving furniture. Furniture can tip over if moved improperly. Improper handling can result in cuts and lacerations. Do not install on sloping surface.




Precaución:

Nunca deje que los niños suban sobre muebles o jueguen con los muebles. No coloque un peso que sea más pesado que la capacidad de carga recomendada en la superficie del mueble.

Tenga cuidado al mover muebles. Los muebles pueden caerse si se mueven de manera incorrecta. No instale en una superficie en pendiente.

LED Remote Operation



Power/Standby

Press to turn remote on or switch to standby. At power on, remote will return to previous setting.

Energía/En Espera

Púlselo para encender el control remoto o pasar al modo de espera. Al encenderlo, el control remoto regresará a la configuración anterior.



Mode +/-

Switch to one of 22 dynamic modes or from static mode.

Modo +/-

Cambie a uno de los 22 modos dinámicos o del modo estático.



Speed +/-

Increase (+) or decrease (-) dynamic mode speed.

Velocidad +/-

Aumentar (+) o disminuir (-) la velocidad del modo dinámico.



Color +/-

Switch to static from dynamic mode or between static colors.

Color +/-

Cambie a estático desde el modo dinámico o entre colores.



Bright +/-

Switch to static from dynamic mode and increase or decrease brightness.

Brillo +/-

Cambie a estático desde el modo dinámico y aumente o disminuya el brillo.

Static Colors

Choose or change to one of 7 static colors.

Colores Estáticos

Elija o cambie a uno de los 7 colores estáticos.
















Demo Mode

Modo de Demostración

SPECIFICATIONS

Dynamic Modes	22
Static Colors	7
PWM Grade	256
Brightness Levels	8
Speeds	6
Demo Modes	17
Voltage	5-24 VDC
Peak Current	3x4A
Average Current	3x2A
Remote Frequency	433.92 mHz
Operating Distance	<26 ft.

Parts List/ Lista de Piezas

Item Artículo	Components Componentes	Qty Cant.	Item Artículo	Components Componentes	Qty Cant.
1		2	10		1
2		2	11		1
3		1	12		1
4		1	A	 1/4*12mm	22
5		1	B	 1/4*52mm	6
6		1	C	 Ø4*16mm	3
7		1	D		1
8		2	E		1
9		1			


1



A x10

Use Allen wrench (D) to attach all bolts. Lay left leg (4) on the floor and attach and tighten crossbars (1, 2 and 3) with two bolts (A) each. Lay assembly with crossbars on the floor. Attach and tighten right leg (5) to crossbars (1, 2 and 3) with two bolts (A) each.

Utilizar la llave Allen (D) para fijar todos los pernos. Coloque la pierna izquierda (4) en el suelo. Fije y apriete los travesaños (1, 2 y 3) con dos pernos (A) cada uno. Coloque ensamblaje con barras transversales en el suelo. Fije y apriete pierna derecha (5) a los travesaños (1, 2 y 3) con dos pernos (A) cada uno.



2




A x4



B x6

Lay desktop upside down on a smooth surface. Place the frame from Step 1 on the desktop (6) and align the holes. Using the Allen wrench (D), attach but do not fully tighten the six bolts (B). Now working in a clockwise sequence tighten the bolts, making sure the frame fits flush against the desktop (6). Attach braces (8) with two bolts (A) each.

Coloque el escritorio al revés sobre una superficie lisa. Coloque el marco del paso 1 en la parte superior del escritorio (6) y alinear los agujeros. Usando la llave Allen (D), fije pero no apriete completamente los cinco pernos (B). Ahora trabajando en una secuencia en el sentido de las agujas del reloj apretar los pernos, asegurándose de que el marco encaje en la parte superior del escritorio (6). Fije las abrazaderas (8) con dos pernos (A) cada una.




3



A x6

Use Allen wrench (D) to attach and tighten all bolts. Attach the power strip tray (7) with four bolts (A). Attach the drink holder (9) with two bolts (A) on either side of the desk.

Utilizar la llave Allen (D) para fijar y apretar todos los pernos. Coloque la bandeja de la regleta de alimentación (7) con cuatro pernos (A). Coloque el portavasos (9) con dos pernos (A) a cada lado del escritorio.




4



C x3

Lift the gaming desk upright as shown. Carefully press the USB hub assembly (12) into the opening until it sits flush with the desktop. Insert USB connector (12) into your laptop USB port. To power LEDs, insert USB connector from LEDs (1) into USB hub (12) or into your laptop USB port. Attach tray holder (11) with three screws (C) using a Phillips screwdriver. Slide tray (10) onto tray holder (11) as shown.

Levante el escritorio de juego como se muestra. Presiona cuidadosamente el ensamblaje del concentrador USB (12) en la abertura hasta que quede a ras del escritorio. Inserte el conector USB (12) en el puerto USB de su portátil. Para encender los LEDs, inserte el conector USB de los LEDs (1) en el concentrador USB (12) o en el puerto USB de tu portátil. Coloque el soporte de la bandeja (11) con tres tornillos (C) con un destornillador Phillips. Deslice la bandeja (10) en el soporte de la bandeja (11).



LED Remote

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

Cautions: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Remote model:ATL008

FCC ID: 2AX3PATL008



©2020 ATLANTIC INC.
All rights reserved / Derechos Reservados
Customer Service/ Servicio al cliente
PO Box 2399
Santa Fe Springs, CA 90670 USA

1-800-747-2660
customer_relations@atlantic-inc.com
www.theatlanticstore.com

Made in China / Hecho en China