

Item 9. In accordance with 2.1033(c)(8), please identify the source of the DC voltages and currents in the documentation provided. Please include, the dc voltages applied to and dc currents into the several elements of the final radio frequency amplifying device for normal operation over the power range.

The Reader input voltage and current is 9 to 18VDC at 2amps maximum.
The power to the final RF power amplifier is +20 volts at 0.5 amps.