G2Z-NCAP User Guide







The Kroger Co. Release 1.0 Version 1.1

Copyright © 2010, The Kroger Co. All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission from The Kroger Co.

All copyright, confidential information, patents, design rights and all other intellectual property rights of whatsoever nature contained herein are and shall remain the sole and exclusive property of The Kroger Co. The information furnished herein is believed to be accurate and reliable. However, no responsibility is assumed by The Kroger Co. for its use, or for any infringements of patents or other rights of third parties resulting from its use.

The Kroger Co. name and The Kroger Co. logo are trademarks or registered trademarks of The Kroger Co. All other trademarks are the property of their respective owners.



Table of Content

| L | INTRODUCTION | | | | | | |
|---|-------------------------------------|-------------------------------------|---|--|--|--|--|
| 2 | G2Z-NCAP SPECIFICATIONS | | | | | | |
| | 2.1 | Processing Network Connections | | | | | |
| | 2.2 | POWER | | | | | |
| | 2.4 | CUSTOMER APPLICATIONS | - | | | | |
| | 2.6 | OPERATING CONDITIONS | | | | | |
| | 2.7 2.8 | DIMENSIONSAPPROVALS | - | | | | |
| | 2.9 | Included Accessories | 6 | | | | |
| | 2.102.11 | Safety Precautions | | | | | |
| 3 | PC | OWER REQUIREMENTS | 8 | | | | |
| 1 | INTERFACE DETAILS | | | | | | |
| | 4.1 4.2 | RS232 Interface: ZigBee Interface: | | | | | |
| 5 | FC | CC COMPLIANCE STATEMENTS1 | 0 | | | | |
| 6 | 0 | PERATIONAL INSTRUCTION1 | 0 | | | | |
| | | | | | | | |

Tables

Table 1: RJ45 Connector Pin Assignment:



Revision History

| Date | Change Description | Revision | | |
|-----------|-----------------------------------|----------|--|--|
| 29-SEP-12 | Initial Revision | 1.0 | | |
| 07-Nov-12 | Updated for Compliance statements | 1.1 | | |



1 Introduction

G2Z-NCAP is a POE powered device ZigBee Access Point device.

Benefits

- Supports time synchronization with a Network Time Protocol (NTP) server.
- Access point for Zigbee Infrastructure.
- Firmware update via LAN



2 **G2Z-NCAP Specifications**

2.1 Processing

- 600Mhz Dual Core SoC
- Upto 256MB DDR2 RAM
- 128MB NAND FLASH
- On-Board ZigBee Modules (4 Nos)
- RS232 Interface
- Monta Vista Linux Kernel

2.2 **Network Connections**

• 10/100 Mbps Ethernet

2.3 Power

Input Voltage: 48VDC (POE)

Input Current: 0.2A

2.4 **Customer Applications**

Access Point

2.5 Firmware Updates

• Firmware updates over the LAN network

2.6 **Operating Conditions**

• Temperature: 5 to 40° C (41 to 104 °F)

• Humidity: 20 to 80% RHG

Indoor use only

2.7 Dimensions

• Height: 30 mm

Width: 179 mmDepth: 179 mm

2.8 Approvals

EMI

o FCC

Safety

o UL

2.9 Included Accessories

Adjustable ceiling mount supporting tile mount, through ceiling mount and tear drop installations.



2.10 Safety Precautions

Below is safety precaution that should be observed when installing device.

2.11 Electrostatic Discharge

The device will be installed over ceiling, there will not threat of ESD during normal operation. The ESD threat will be further reduced due to plastic casing.

The installation of the device will be done through trained person. The person should take care of ESD precautions while installing device.



3 Power Requirements


The G2Z-NCAP can be powered through PoE Adapter or PoE Switch through RJ-45 Ethernet connector. Being 802.3af compliant device, G2Z-NCAP would draw 10W (< 13W as per PoE standard) power from PoE source.

The PoE Adapter/Switch is not part standard packaging. The standard 802.3af Compliant, FCC/CE/UL certified off-the-shelf devices should be used to avoid interference issues to G2Z-NCAP.

If multiple G2Z-NCAP will be powered from single multiport Ethernet switch, proper power rating should be selected to meet individual power requirements of G2Z-NCAP.

• Specifications for suitable PoE Injector or Switch are as follows:

Input Voltages: 90–264 VAC, 60Hz
 Output Voltage (Typ): 48 VDC
 Output Current: 0.32A per Port
 Power: 15.36W per Port



| Standard | Source | RJ45 Pin Number | | | | | | | |
|--------------|----------|-----------------|-----|-----|-----|-----|-----|-----|-----|
| Standard | Voltage | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| IEEE 802.3af | | | | | | | | | |
| using Spare | 48-56VDC | TX+ | TX- | RX+ | DC+ | DC+ | RX- | DC- | DC- |
| Data pairs | | | | | | | | | |

Table 1: RJ45 Connector Pin Assignment:



4 Interface Details

G2Z-NCAP Device provides RJ45 interface for Network connectivity. The Ethernet interface is the only available interface to the outside world. Apart from RJ45, G2Z-NCAP provides ZigBee wireless connectivity through on-board ZigBee modules.

Interfaces available on-board G2Z-NCAP:

4.1 RS232 Interface:

On Board RS232 interface is not accessible from outside enclosure.

4.2 **ZigBee Interface:**

G2Z-NCAP has 4 ZigBee modules for wireless connectivity.



5 FCC Compliance Statements

This device complies with Part 15 of the FCC rules. Operation is subject to following two conditions:

- 1. This device may not cause harmful interference and
- 2. This device must accept any interference received including interference that may cause undesired Operation of this device.

FCC Caution: Any changes or modifications not expressly approved by the party responsible For compliance could void the user's authority to operate this equipment.

To comply with the FCC RF exposure compliance requirements, this device and its antenna must not be co-located or operating to conjunction with any other antenna or transmitter, except if installed in compliance with FCC Multi Transmitter procedures.

The equipment should be installed and operated with Minimum distance of 20cm between Radiator and Your Body.

Snap-On Ferrite Core 28A2025-0A2 (Make: Liard Signal Integrity Products) need to be mounted on Ethernet Cable near RJ45 connector of G2Z-NCAP. This ferrite core was used during testing to achieve compliance.

6 **Operational Instruction**

For G2Z-NCAP operational instruction, please contact Vendor/Manufacturer for latest updated instruction guide.