


Download Amber Manager App to your mobile phone.








O2 Connect network cable to blue port on Amber.


1. If using a standalone modem, connect the other end to Network port.



2. If using a combination modem/router, connect the other end to LAN port


• The color of the WAN and LAN ports are not necessarily as shown - please


read the label on your modem device.



Connect power cable, then power on.

Wait for LED ring to turn yellow and go to next step.





FCC ID: 2AP7A-AMBER12

This device complies with Part 15 of the FCC Rules. Operation is subject to the following Hereby, Latticework, Inc. declares that the radio equipment type AM12 is in

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed AT, BE, BG, CZ, DK, EE, FR, DE, IS, IE, IT, EL, ES, CY, LV, LI, LT, LU, HU, MT, NL, NO, PL, PT, installation. If this equipment does cause harmful interference to radio or television encouraged to try to correct the interference by one of the following measures: Before starting removing or replacing the hard disk drive, power off the product and wait

Reorient or relocate the receiving antenna.

 Any changes or modifications not expressly approved by the party responsible for 經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自變更頻

other antenna or transmitter.

uncontrolled environment. This equipment should be installed and operated with 電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之 minimum distance 20cm between the radiator & your body. Note: The country code selection is for non-US model only and is not available to all US model. Per FCC regulation, all Wi-Fi product marketed in US must fixed to US

This device complies with Directive 2014/53/EU issued by the Commission of the

A minimum separation distance of 20 cm must be maintained between the user's body and the device, including the antenna during body-worn operation to comply with the

RF exposure requirements in Europe.

Frequency band(s) in which the radio equipment operates;

Accessories and components including software which allow the radio equipment to operate as intended. Manufacturers only have to describe those accessories and

components including software if they: have an influence on the conformity of the radio equipment, and are intended to be installed or changed by the user without the control of the manufacturer. The instructions shall also include information required as above.

Operating temperature: 0° C to 40°C

Repair or disassemble

When replacing the lithium coin cell battery, use only the same or an equivalent type that is recommended by the manufacturer. The battery contains lithium and can explode if not properly used, handled, or disposed of.

Throw or immerse into water



Model: AM12 Personal Hybrid-Cloud

Amber Life

本設備可能包含會影響健康和環境的有害物質。



2210 O'Toole Ave. Suite 250. San Jose, CA 95131, USA

electrostatic discharge (ESD). To reduce the chance of ESD damage, work over a

 任功率射期電機之使用不得影響飛航安全及干擾合法涌信;經發現有干擾現象時,應立 即停用,並改善至無干擾時方得繼續使用。前項合法通信,指依電信法規定作業之無線

 回收系統將採用健全的機制,在設備使用期限終止時重複使用或回收設備的大部分材料 • 如果您需要收集、重複使用和回收系統的詳細資訊,請聯絡您當地或地區的廢棄物管理


率、 加大功率或變更原設計之特性及功能。




Desktop Setup

Connect network cable to blue port on Amber.

1. If using a standalone modem, connect the other end to Network port.



2. If using a combination modem/router, connect the other end to LAN port.




• The color of the WAN and LAN ports are not necessarily as

shown - please read the label on your modem device.

Desktop Setup


2 Connect power cable, then power on.

Wait for LED ring to turn yellow and go to next step.




Desktop Setup

- O3 Connect Desktop to Amber Network with one of the following methods.
- 1. Connect Desktop/Laptop LAN cable to Amber LAN port.



2. Find WiFi SSID (Network Name) and connect to the Amber WiFi.




WiFi SSID and password.



• Use the preset WiFi SSID and password on the label to connect to Amber WiFi network.

Go to https://latticerouter.local and follow the guide to complete setup.



• Different PC platforms may cause trouble of using above URL. Please connect 192.168.0.1 if you cannot access Amber. For more details, please see www.myamberlife.com/support/setur

SPEC Overview

WPS

Amber LED Ring Indicators

- White Blinking: Amber is booting up.
- Cyan Solid: Amber is working well.
- Amber Blinking: Amber is shutting down.
- Blue Solid: Amber is in network Red Related: System errors.
 - only mode.

Cyan Blinking: Amber lost

Internet connection.

USB 3.0 Port Type-A

- Power Connector

For more information, please see https://www.myamberlife.com/support/