

# H19022-RGB

## PARAMETER

MODEL:	H19022-RGB	POWER:	45W
CRI:	≥95	LED QTY:	(80RGB+W224+Y224)PCS
DIMMER:	0%~100%	SIZE:	19inch/48.2CM
INPUT VOLTAGE:	DC 15V3.2A		
COLOR TEMPERATURE:	3200~5600K		
MODE SELECTION:	CCT/HSI/SCENE		



CCT: 3200~5600K



HSI:0~360°




SCENE:9 light effect



### Warning


- Do not look directly into the luminescent surface for a long time, otherwise it may cause some damage to vision.
- Do not use cloth or other articles to cover the heat dissipation hole on the product. Otherwise, the product may be damaged.
- Do not touch the lamp with wet hands to avoid potential safety hazards.
- Do not remove or modify the circuit of the item; Do not expose yourself to the sun.
- Please close this product when not in use.
- Failure to comply with the operating procedures and warnings in this manual is not covered by the warranty.



- Power switch: 0 power off;  
I Adapter power ; II Battery power
- Input power socket: DC 3.5~2.3mm
- Function switch button: CCT mode; HSI mode; SCENE mode
- MIN&MAX knob: brightness adjustment knob
- W&C knob: color temperature adjustment knob
- USB port: 5V1A
- Battery storage: battery model F550/750/970
- Channel number: When multiple lights are used at the same time, the APP controls the single light  
Channel adjustment: press and hold the function switch button for three seconds, adjust the W&C knob to adjust the channel

## Mobile APP or Applet of WeChat control

- Scan the QR code to download the "Hoopoetry" APP or applet of WeChat QR code;
- Turn on the mobile phone Bluetooth and entry APP, then select Visitor or sign in. Or Entry applet of WeChat;
- Select to add device, match "hoopoetry light", after the connection is successful, it can be controlled remotely.



Applet of wechat



Download APP

### CCT MODE

MIN&MAX knob to adjust brightness W&C knob to adjust color temperature  
(9) Brightness adjustment display: 0%~100%  
(10) Color temperature adjustment display: 3200K~5600K  
(11) Bluetooth connection: When the device is turned on, the bluetooth logo flashes, The device is in standby.

### HSI MODE

Short press the W&C key to select the color and saturation, under the corresponding item, Rotate the W&C knob to adjust the corresponding value. Adjustment in this mode The MIN&MAX knob can adjust the brightness.  
(12) Brightness adjustment display: 0%~100%  
(13) Color value display: 0°~360°  
(14) Saturation display: 0~100 (A0)

### SCENE MODE

The device has built-in 3 types and 9 light effect modes. In this mode, short press MIN&MAX key to switch the light effect category, and turn the DIM knob to switch the light effect mode. In this mode, adjusting the MIN&MAX knob can adjust the brightness.  
(15) Brightness adjustment display: 0%~100%  
(16) Light effect category: ⚠ warning, 🌩 atmosphere, ⚡ flash  
(17) Light effect mode: A police car, B ambulance, C fire truck;  
A Fireworks 1, B Fireworks 2, C Party;  
A Lightning 1, B Lightning 2, C Screen

WeChat public account:



Official website: [www.hoopoetry.com](http://www.hoopoetry.com)

### FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### RF Exposure

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.